

MULTI-AMP[®]
BIDDLE[™]
MEGGER[®]

**Electrical Test Equipment
Measuring Instruments
Testing and
Training Services**

AVO



AVO INTERNATIONAL

multi-amp CORPORATION

4271 Bronze Way Dallas, Texas 75237-1088 U.S.A.
Ph. (214) 333-3201 Telex 163548 MULAM DL Fax (214) 333-3533

Multi-Amp Canada, 445 Finchdene Square, Scarborough, Ontario, M1X 1B7
Ph (416) 298-6770 Telex 065-25453 Fax (416) 298-7214

INSTRUCTION MANUAL

For

DIGITAL PHASE ANGLE METER

MODEL PAM-275

It is essential that this instruction book be read thoroughly before putting the equipment in service.

Part N° 12551
Rev. 1 8/15/91

IMPORTANT

The information and data contained within this instruction manual are proprietary with MULTI-AMP Corporation. The equipment described herein may be protected by one or more U.S. letters patent. MULTI-AMP specifically reserves to itself all rights to such proprietary information as well as all rights under any such patent, none of which is waived by the submission of this instruction manual to anyone.

The recipient, if a Government agency, acknowledges that this instruction book and the equipment described were procured with "Limited Rights" to technical data as described in ASPR 9-203 (b).

Copyright MULTI-AMP Corporation, 1984, 1985, 1988, 1991

Part Nº 12551
Rev. 1 8/15/91

TABLE OF CONTENTS

SECTION	PAGE
I. General Description and Specification	Bulletin
II. Operating Features	
A. Safety Precautions	1
B. Description of Controls	1
C. Selection of Power Source	1
D. Input Fuses	2
E. Input Circuits	2
F. Digital Display	2
G. Low Input Indication	2
H. High Input Indication	2
I. Accuracy Levels	3
J. Hold Reading Feature	3
K. Zero Check Feature	3
III. Operating Instructions	
A. Theory of Operation	4
B. Power Connection and Turn On Procedures	4
C. Phase Angle Measurements	4
D. Operation Below Range Limits	5
E. Operation Above Range Limits	5
F. Applications	5
1. Determining Polarity of Current Transformers	5
2. Determining the Power Factor Angle of an Inductive Circuit	6
3. Determining the Power Factor Angle of an Capacitive Circuit	7
4. Determining Real and Reactive Power Flow in a Power System	8
5. Verifying Connections to a Power Directional Relay with a Delta Connected Potential	9
6. Verifying Connections to Transformer Rated Watthour Meters	10
a. 3Ø 4 Wire Y 3 Element	10
b. 3Ø 4 Wire 2 Element	10
c. 3Ø 4 Wire Delta 3 Element	11
IV. Service Data	
A. Calibration Check	19
B. Trouble-Shooting and Repair Procedure	19
C. Service and Repair Order Instructions	24
D. Warranty Statement	25

Digital Display

0.0 to 359.9°

PAM-275R: Nonfllickering, 0.6-in.

(15-mm) LED numerals

PAM-275B: 0.5-in. (12-mm)

LCD numerals

Current (both inputs)

Range	Accuracy	Resolution	Burden
0.05 – 2.0 A	±0.5°	0.1°	0.32 VA at 2 A
1.5 – 60 A			2.5 VA at 60 A

Useful down to 0.015 A and up to 120 A at reduced accuracy

Voltage (both inputs)

Range	Accuracy	Resolution	Burden
1 – 40 V	±0.5°	0.1°	4.7 kΩ
15 – 600 V			71 kΩ

Useful down to 0.25 V and up to 1200 V at reduced accuracy

Isolation

Each input circuit is isolated from the other and from ground.

Input Frequency Range (specify one)

58 to 62 Hz OR 48 to 52 Hz

Overload Capability

120 A for 1 min on high range

35 A for 1 min on low range

1200 V for 1 min on high range

120 V for 1 min on low range

Measurement Rate

Two measurements per second. Readings are held between measurements to avoid flickering.

Environmental**Temperature Range:** 10 to 110° F

(-12 to +43° C)

Warm-Up Time: Approx 1 min**Enclosure**

The instrument is housed in a high-strength, molded suitcase-style case with carrying handle, removable hinged cover and lead compartment.

Dimensions**(including removable cover)**

8.5 H x 12 W x 9.0 D in.


216 H x 305 W x 229 D mm

Weight

12 lb (5.5 kg)

ORDERING INFORMATION

Item	Cat. No.	Item (Qty)	Cat. No.
Model PAM-275 with:		Included Accessories	
LCD Display		Line cord (1)	6828
115-V, 60-Hz input	PAM-275B-115/60	Fuses, 0.125, 250 V MDL (5)	981
LCD Display		Instructional manual (1)	9160
230-V, 50-Hz input	PAM-275B-230/50		
LED Display		Optional Accessories	
115-V, 60-Hz input	PAM-275R-115/60	Leads	
LED Display		5 ft [1.5 m] (1 pr)	7933
230-V, 50-Hz input	PAM-275R-230/50	Low-current, 5 ft [1.5 m] (1 pr)	7934
		High-current, 5 ft [1.5 m] (1 pr)	7935



MULTI-AMP Model PAM-275

- Reliable
- Rugged
- Easy-to-use
- Battery-operated

Digital Phase Angle Meter

DESCRIPTION

The Multi-Amp Model PAM-275 Digital Phase Angle Meter was designed specifically for electrical system applications. It is a battery-operated (rechargeable) or line-powered instrument. Incorporating two identical isolated input circuits, the unit permits precision measurements to be made of the phase angle relationship between two currents, two voltages or a voltage and a current.

APPLICATIONS

Model PAM-275 is commonly used in testing and calibrating protective relays, phasing out circuits, checking differential relay schemes, checking polyphase watt-hour and var-hour meter installations and verifying the polarity of CTs and PTs.

FEATURES AND BENEFITS

- Direct digital reading
- Broadband current ranges
- Broadband potential ranges
- Excellent resolution
- Highly accurate
- Universal: measures I to I, E to E, E to I
- Long battery life
- Isolated input circuits
- Harmonic immunity: accurate reading with up to 30% harmonic distortion
- Not frequency-sensitive: accuracy not dependent on precise 50- or 60-Hertz inputs
- Rugged: Sturdy design provides years of typical field use.

- Out-of-range indication: automatic indication given when inputs are above or below rated ranges, eliminating need for instruments to monitor inputs
- Hold feature
- Not influenced by position

SPECIFICATIONS

Input (for battery recharging or line operation)

Nominal 115 or 230 V (switch-selected), 1 or 25 VA. Instrument may be used while battery is being recharged.

Battery Capacity

Minimum 8 hours of continuous usage on a single full charge. Low-battery condition is indicated by flashing decimals. Recharge time is twice the time used on battery power. The battery charger is built-in.

OPERATING FEATURES

SAFETY PRECAUTIONS

CAUTION

ALL UNITS ARE SHIPPED FROM THE FACTORY SET-UP FOR OPERATION FROM A NOMINAL 115 VOLT POWER SOURCE. IF THE UNIT IS TO BE USED ON A 230 VOLT SOURCE, IT IS NECESSARY FOR THE OPERATOR TO FIRST ADJUST THE POWER SOURCE SELECTOR SWITCH FOR 230 VOLT OPERATION. REFER TO "SELECTION OF POWER SOURCE" ON PAGE 1 FOR DETAILS.

POWER ON Switch ON/OFF Switch for input power for logic and display.

1/8 Amp, 120/240 volts Protects power supply input.

ZERO CHECK Switch Self-checks instrument calibration.

HOLD READING Switch Instrument will retain whatever measurement is being displayed when this switch is turned on.

DISPLAY RESET Switch When toggled, the battery operation is reset for approximately five (5) additional minutes.

DISPLAY TEST Switch All segments of each numeral are displayed (all 8's) to verify proper operation.

INPUT 1 & 2 Binding Posts

1.5 - 60 amps (Black)	High current input range.
0.05 - 2.0 amps (Black)	Low current input range.
15 - 600 volts (Red)	High potential input range.
1 - 40 volts (Red)	Low potential input range.
COMMON $\pm$ (White)	One side of the input signal (both current and potential) connects to either terminal.

INPUT 1 LAGS INPUT 2 Displays Indicates phase angle in degrees.

SELECTION OF POWER SOURCE VOLTAGE:

All Model PAM-275 units are manufactured as dual voltage 120/240 volt units and are shipped from the factory with the power source VOLTAGE SELECTOR Switch set for nominal 120 volt operation. Power source voltage selection is adjustable by the use of a three-position slide switch. The switch has positions of 240/OFF/120.

The 240/OFF/120 Switch is located on the lower right side of the circuit board next to the transformer, with the 240 volt position to the top, the center position off, and the 120 volt position to the bottom. This switch is in the 120 volt position when shipped from the factory.

To obtain access to the power source VOLTAGE SELECTOR Switch, disconnect unit from source of power, remove instrument from case by loosening four mounting screws (next to INPUT Terminals) and lift chassis out of case. Remove the circuit board by removing the four mounting screws on the bottom of the chassis.

INPUT FUSES:

All units are shipped from the factory set up for nominal 120 volt operation. A $1/8$ ampere fuse is installed in the input fuse socket.

Five spare fuses are supplied with each new unit.

INPUT CIRCUITS:

Model PAM-275 measures and displays the phase angle relationship between two single phase ac signals applied to its input circuits.

Two identical input circuits are provided to facilitate measurements between two voltages, two currents or a voltage and a current. Each input circuit has binding posts for connecting the input signals. The two White binding posts labeled **COMMON ±** are used for both potential and current inputs. Although the two White binding posts are electrically the same point, the larger one should be used for currents in excess of 30 amperes. Either White binding post can be used as the common for potential inputs. Current inputs are applied to a White common binding post and the appropriate Black binding post as determined by the value of current. Potential inputs are applied to a White common binding post and the appropriate Red binding post as determined by the value of potential.

DIGITAL DISPLAY:

The digital display indicates the phase angle in degrees that the signal applied to INPUT 1 lags the signal applied to INPUT 2.

LOW INPUT INDICATION:

If the magnitude of one of the inputs is below the rating of the input range being used, the display will flash. The input can be moved to the low range (if it is not already connected there) and the display will indicate the phase angle, provided that the input is within the rating of this range. However, if the input is below the minimum rating of the lowest range, the display will continue to flash. A reading can be obtained for inputs below the minimum rating, however, the error in measurement can be greater than that for inputs within the instrument's rated ranges.

HIGH INPUT INDICATION:

If the magnitude of one of the inputs is above the rating of the input range being used, the display will blink (flash on and off). The input can be moved to the high range (if it is not already connected there), and the display will stop blinking provided that the input is within the rating of this range. However, if the input is above the maximum rating of the highest range, the display will continue to blink. When the display blinks, the error in measurement can be greater than that for inputs within the instrument's rated range.

ACCURACY LEVELS:

Model PAM-275 is calibrated at the factory to measure the phase angle within rated accuracy for all input signals that are within the rated input ranges. On most units, if a low or high signal slightly outside the rated input ranges is applied, the meter will continue to accurately make its measurements. This is because the meter is factory calibrated to be within rated accuracy over the complete range at which it indicates without the display flashing.

HOLD READING FEATURE:

If it is desirable to retain the reading displayed, simply use the HOLD READING Switch. Whatever measurement is being displayed at the time this circuit is actuated, will be held until the switch is turned off. The reading is held even when the input signal is removed.

ZERO CHECK FEATURE:

Instrument calibration can be readily checked by use of the ZERO CHECK Switch.

To perform zero check, allow instrument to warm up for 10 minutes and then apply either approximately 5 amperes to the 1.5 - 60 amperes range of INPUT 2 or approximately 120 volts to the 15 - 600 volts range of INPUT 2. Connection to INPUT 1 is not required. Then turn the ZERO CHECK Switch on and the display should read between 359.8 and 0.2.

No adjustment is necessary if the reading is within these limits. Model PAM-275 is designed to minimize drifting, however, if zero check is outside these limits, the instrument can be recalibrated as follows:

1. Turn POWER Switch on and HOLD READING Switches OFF and disconnect all inputs, including the input line cord, from their source.
2. Remove the instrument from the case by removing the four mounting screws (next to the input terminals) and sliding the instrument out.
3. Place unit on table or bench top with its panel horizontal
4. Reconnect input line cord to the power source and turn POWER ON Switch ON.
5. Apply current or potential input to INPUT 2 as outlined above.
6. Turn ZERO CHECK Switch ON.
7. Locate and adjust trim pots R1 and R21 (Input 1 and 2) until display indicates between 359.8 and 0.2. These trim pots are located at the bottom left side of the board. No other adjustments should be made without contacting the factory.
8. Re-install instrument in its case.

OPERATION INSTRUCTIONS

THEORY OF OPERATION

The Model PAM-275 Digital Phase Angle Meter operates by measuring the elapsed time between the zero cross-over of Input 2 versus Input 1. The input signal of each input is filtered to minimize the harmonic distortion that may be present. The filtered sine wave is then converted to a square wave. The two square waves are compared by the logic circuit. The result of the comparison is a square wave pulse train, which is an accurate measurement of the elapsed zero cross-over between the two inputs. This pulse train is then converted by the logic circuit to a phase angle and displayed on the digital readout.

POWER CONNECTION AND TURN ON PROCEDURES:

1. Refer to Selection of Power Source Voltage on Page 1 before connecting instrument to a power source.
2. Check to insure POWER ON Switch is in the OFF position.
3. Connect the instrument to a suitable source of power. Check third wire in line cord to insure that the instrument is properly grounded to prevent any shock hazards.
4. Check to insure that the HOLD READING Switch is OFF. Turn POWER ON Switch ON.
5. Press Display Check Switch, all eights (888.8) should appear.

PHASE ANGLE MEASUREMENTS:

1. Connect either a current or potential to the appropriate binding posts of INPUT 1. Do not connect more than one input. For example, do not connect a current and a potential source simultaneously to INPUT 1.
2. Connect either a current or potential source to the appropriate binding posts of INPUT 2. Again, do not connect more than one source to INPUT 2.

CAUTION: Do not connect a potential source to the current input terminals.

3. Display will now indicate the phase angle that INPUT 1 lags INPUT 2. If display is blinking, a high or low level input is present or the battery is low. See Pages 2 and 3 for further details on LOW INPUT INDICATION, HIGH INPUT INDICATION and ACCURACY.

NOTE: It is suggested to use color-coded test leads with the same color to the binding posts with the polarity marks.

OPERATION BELOW RANGE LIMITS:

The normal Model PAM-275 can be used for measuring phase angles below the meter's normal range limits.

In the lower current range 0.05-2.0 amperes, the Model PAM-275 can be used to measure phase angles with as little as 0.015 amperes input. In the lower voltage range 1-40 volts, the Model PAM-275 can be used to measure phase angles with as little as 0.25 volts input. However, the error in measurement will be greater than that for inputs within the instrument's rated ranges. When the magnitude of either the voltage or current drops below the lowest rating of the lowest input range, the display will flash zero (000.0).

OPERATION ABOVE RANGE LIMITS:

The Model PAM-275 may be used for measuring phase angles above the meter's normal range limits; however, it is not recommended.

In the upper current range 2-60 amperes, the Model PAM-275 may be used to measure phase angles with currents above 60 amperes input. In the upper voltage range 20-600 volts, the Model PAM-275 may be used to measure phase angles with voltages above 600 volts input. When the magnitude of either the current or voltage rises above the rating of the highest input range, the display will begin to flash on and off. In no case should an overload greater than 100% be applied to the meter. If a reading is still required, and the inputs are below the 100% overload limit, a reading may be obtained by connecting the inputs to the proper terminals. However, if an overload is applied for more than one minute, damage may result to the meter.

APPLICATIONS:

The phase angle meter has many uses. Certain terms will be used in this section which need to be defined.

1. Phase Angle is normally expressed in degrees. It is the angle between two sources, i.e., voltage leading or lagging current between 0° and 359.9° .
2. Power Factor is the cosine of the leading or lagging phase angle between a voltage and a current. It is either expressed as a decimal fraction or as a percent.
3. Power Factor Angle is the leading or lagging phase angle between the voltage and current.

A. Determining Polarity of Current Transformers

When current is induced into polarity of the primary of a current transformer, the current will flow out of polarity on the secondary, see Figure 1.




FIGURE 1: Direction of Secondary Current in a C. T.

Using a current transformer of known polarity. The current transformer of unknown polarity can be determined with a phase angle meter. Connect the two current transformers to the phase angle meter as shown in Figure 2.




FIGURE 2: Determining Current Transformer Polarity

CAUTION: Do not open the secondary of the current transformers with the current source energized.

If the polarities are the same, a phase angle of zero degrees should be indicated. If a reading of 180 degrees is indicated, the polarity is opposite that of the known current transformer.

B. Determining the Power Factor Angle of an Inductive Circuit.

The current in a power system represents both real and reactive power. To determine how much of the current is being used to power an inductive load, connect the phase angle meter as shown in Figure 3. Note that the current lags the voltage in an inductive circuit, therefore, the current is supplied to INPUT 1. The phase angle displayed is the Power Factor Angle between the lagging current on INPUT 1 and the voltage on INPUT 2. If the load were a pure inductive load, the phase angle would be close to 90° or a Power Factor of 0% (cosine of 90° is 0.0).




FIGURE 3: Angle between a Current and a Voltage (Induction Circuit).

C. Determining the Power Factor Angle of a Capacitive Circuit.

To determine how much of the current is being used to power a capacitive load, connect the phase angle meter as shown in Figure 4. Note that the current leads the voltage in a capacitive circuit, therefore, the current is supplied to INPUT 2. The phase angle displayed is the Power Factor Angle between the lagging voltage on INPUT 1 and the current on INPUT 2. If the load were a pure, capacitive load, the phase angle would be close to 270° or a Power Factor of 0% (cosine of 270° is, 0.0).




FIGURE 4: Angle between a Current and Voltage (Capacitive Circuit).

- D. Determining Real and Reactive Power Flow in a Power System. The phase angle meter shown in FIGURE 5, will read any angle from 0 to 359.9 degrees depending upon the direction of real and reactive power flow. If real power is leaving the bus and reactive is entering, the reading should be from 270° to 359.9°. If on the other hand, real power is entering and reactive is leaving the bus, the reading should be from 90° to 180° to 270°. If both real and reactive power are entering the bus, the reading should be from 180° to 270°. If both real and reactive power is leaving the bus, the meter should read from 0° to 90°.




FIGURE 5: Determining Real and Reactive Power Flow

E. Verifying Connections to a Power Directional Relay with a Delta Connected Potential.

When checking power directional relays, or any three-phase relay with a Delta-connected potential source, the voltage reference is phase-shifted 30° . With the phase angle meter connected as shown in FIGURE 6, the meter will read 30° lagging when the current is leaving the generator at unity power factor.




FIGURE 6: Verifying Connections to a Power Directional Relay With a Delta Connected Potential.

F. Verifying Connections to Transformer Rated Watthour Meters.

This section covers the use of the phase angle meter to check connections of transformer rated watthour meters. The procedure outlined provides a simple means where the average meter technician can easily and accurately check the connections of transformer rated watthour meters.

Three types of meters are shown:

3Ø 4 wire delta, 3Ø 4 wire Y, and 3Ø 3 wire 2 Element. There are other types, the techniques shown in this section may be modified to verify other forms of metering.

The vectors shown are plotted as conventional polar and are shown in a counter-clockwise rotation.

It is assumed that the operator of this equipment has the knowledge and technical ability to properly connect the meter as shown in the examples. If the operator is unfamiliar with the meter and its operation, it is suggested that he thoroughly read and understand the Operating Instructions beginning on Page 4.

When making phase angle measurements, it is suggested that the operator put an ammeter in series with the current leg to the phase angle meter. Measure the phase angle when the currents are about equal (this will insure higher accuracy for changing load conditions).

3Ø 4 WIRE Y 3 ELEMENT

Connect the phase angle meter to phase A, see FIGURE 7. Note, in this example the phase angle meter is shown connected to phase C for simplicity. After connecting the phase angle meter, measure the angle, record, and plot it as shown in FIGURE 8. Repeat the procedure for B and C phases. If the measurements and installation are correct, the potentials will be 120° apart.

If the load is closely balanced, the Power Factor can be determined by averaging the three angles together. As in the example, in FIGURE 8 the average of the three angles is 30°. The cosine of 30° is 0.87 or a Power Factor of 87%.

3 Ø WIRE 2 ELEMENT

Connect the phase angle meter as shown in FIGURE 9. In this example, the phase angle meter is connected to C phase for simplicity. Measure the potential vectors V_{A-B} , V_{B-C} , and V_{C-A} repeat the procedure for I_A . After the polar plot is completed, similar to Figure 10, plot a system delta diagram paralleling the original polar vectors, see Figure 11. The hypothetical V_{A-O} and V_{C-O} are established by bisecting the angles B-A-C. After and A-C-B. These vectors will be 30° away from the basic potential vectors and establish the unity power factor point for a 3 wire delta system. With a protractor, determine the angle between V_{A-O} and I_A and V_{C-O} and I_C . The cosine of the average of these two angles is the calculated power factor, see FIGURE 12.

3 Ø 4 WIRE DELTA 3 ELEMENT

Connect the phase angle meter as demonstrated in FIGURE 13. In FIGURE 13, the phase angle meter is connected to C phase for simplicity. Measure the potential vectors V_{A-B} , V_{B-C} , and V_{C-O} are established by bisecting the angles. These vectors will be 30° away from the basic potential vectors and establish the unity power factor point for a 4 wire delta system. With a protractor determine the angle between V_{A-O} and I_A , V_{B-O} and, and V_{C-O} I_B and I_C . The cosine of the average of these three angles is the calculated power factor, see FIGURE 16.

3 Ø 4 WIRE 3 ELEMENT



3 Ø 4 WIRE Y 3 ELEMENT




FIGURE 7: Verifying Connections of 3Ø 4 Wire Y 3 Element Meters

3 Ø 4 WIRE Y METER

IA

VA-N 28°

V-N 268°

VC-N 148°

IB

VB-N 30°

VC-N 270°

VA-N 150°

IC

VC-N 32°

VA-N 272°

VB-N 152°




FIGURE 8

3 Ø 3 WIRE 2 ELEMENT




FIGURE 9

3 Ø 3 WIRE METER PHASE ANGLE VECTOR

PHASE ANGLE VECTOR

IA		IC	
VA-B	<u>60°</u>	VA-B	<u>300°</u>
VB-C	<u>300°</u>	VB-C	<u>180°</u>
VC-A	<u>180°</u>	VC-A	<u>60°</u>




FIGURE 10

SYSTEM VECTOR




FIGURE 11

3 Ø 3 WIRE METER OVERLAYING SYSTEM VECTOR ON METER

PHASE ANGLE VECTOR

IA

IC

VA-B 60°

VA-B 300°

VB-C 300°

VB-C 180°

VC-A 180°

VC-A 60°




FIGURE 12




FIGURE 13: Verifying Connections of 3Ø 4 Wire Delta Meters

SERVICE DATA

CALIBRATION CHECK:

It is recommended that the Model PAM-275 be periodically tested to check calibration.

A quick and easy calibration check can be made by following the **ZERO CHECK** procedures on Page 3. This calibration check will provide an easy and efficient test of the instrument's circuits. If out of calibration, follow the step by step calibration procedures on that page.

If the meter is still out of calibration, it is recommended that the meter be sent to Multi-Amp Corporation, Service And Repair Department for repair and recalibration. However, if desired, the problem may be isolated. To isolate the problem, it is recommended that the user refer to the following **TROUBLE-SHOOTING AND REPAIR PROCEDURE**.

TROUBLE-SHOOTING AND REPAIR PROCEDURE:

Trouble-shooting Procedures list steps to follow to locate the cause of abnormal conditions encountered during checkout or operation of the Model PAM-275.

Trouble-shooting

Some of the most common problems in making correct phase angle measurements are due to incorrect connections. The following are typical abnormal indications and probable causes.

METER INDICATION	PROBABLE CAUSE
Digital Readout all 000.0's	One or both units are below input range. Go to next lower range. Refer to Page 5, Operation Below Range Limits.
Digital Readout Flashing	<u>WARNING OVERLOAD.</u> One or both inputs are below or above range limits, disconnect inputs and refer to Page 5, Operation Above Limits, or the battery may need recharging.
Phase Angle appears to be 180° above or below expected value.	Polarity of either input is reversed. Reverse leads on one input.

Phase Angle appears to be grossly inaccurate

Connections to Input 1 and Input 2 have been reversed causing the lead and lag to be reversed. Reverse inputs, or the battery may need to be recharging.

The Digital Readout does not change

Check the Hold Reading Switch

Digital Readout Dim

Input voltage to the meter too low.

No Digital Readout

Check input fuses. Input voltage may be too low, refer to SELECTION OF POWER SOURCE INPUT, Page 2. Battery may be discharged.

If the problem is not external to the meter, it may be isolated internally by following the recommended repair procedures.

If a spare replacement printed circuit board is stocked, the following repair procedure should be followed:

1. Install a new printed circuit board, Assy PN 10275.
2. Check calibration of unit by following the Zero Check Procedure on Page 3.
3. If unit cannot be recalibrated, it is recommended the unit be returned with defective board to Multi-Amp Corporation, Service and Repair Department for repair and recalibration. See instructions on Page 23. For details.

If a spare replacement printed circuit board is not available, the following equipment will be required to isolate the defect.

- 1 ea. Millivoltmeter capable of measuring a voltage of 500 mvac rms with accuracy of $\pm 1\%$.
- 1 ea. D.C. voltmeter capable of measuring from 5-20 volts d.c. with an accuracy of $\pm 1\%$.
- 1 ea. Oscilloscope for observing waveform.
- 1 ea. Voltage source, see below.
- 1 ea. A. C. voltmeter capable of measuring up to 120 volts with an accuracy of $\pm 1\%$.


If the required equipment is not available or trained technical personnel are not available, it is recommended the unit be returned to the factory for repair and recalibration.

Additionally, before starting trouble-shooting repair procedure, it is recommended that if the test technician has not read the instruction manual, that he or she do so before starting repair procedures.

WARNING: Circuits will present a shock hazard during trouble-shooting procedure.

TESTING AC POWER SUPPLY AND ANALOG/LOGIC SECTION

1. Turn POWER ON Switch OFF. Check to insure HOLD READING Switch is in the OFF position. Disconnect the inputs and power line cord from their sources.
2. Remove the instrument from the case by loosening the two mounting screws from the case and lifting the instrument out.
3. Remove the printed circuit board and display assy from the chassis, do not remove the ribbon connector. Display module (assy) must be removed if extension cable is not available.
4. Connect the 1-40 volt terminals of Inputs 1 and 2 in parallel with A.C. voltage source, see below. **CAUTION: DO NOT** connect the voltage source to the current terminals.



180° Phase Shift Circuit

5. Connect the Model PAM-275 to a proper voltage source and switch POWER ON Switch to ON position.
6. Using the d.c. voltmeter, measure the voltage levels of the Power Supply, refer to schematic for pin numbers and proper voltage levels. If proper voltage levels are not present, Power Supply needs to be repaired. If proper voltage levels are present, proceed to next step.

TEST POINTS

MEASURE

TP6 (+) and TP10 (-) + 4.75 to + 5.25 VDC.
TP8 (+) and TP10 (-) + 14.50 to + 16.50 VDC.
TP9 (-) and TP10 (+) - 14.50 to - 16.50 VDC.

NOTE: The $\pm$ voltages at TP8/TP9 (to TP10) must be within 0.5 VDC of each other.

7. With A-C test signal applied to input terminals, measure sine wave at TP1 and TP10

(ground) for input 2. Measure sine wave at TP2 and TP10 (ground) for input 1. The amplitudes of the sine wave signals should be approximately the amplitudes of the input signal times 0.2. For example, a 24 vac input on input 1 should produce a 4.8 VAC signal at TP2 (ground reference to TP10).

If the input signals are not present or if improper amplitude, check input transformers T1 and T2 for open windings or significant ohmic variance between the same circuits of the two transformers.

If the inputs signal levels at TP1 and TP2 appear normal proceed to the next step.

8. With signal applied as in step 7, check the voltage level at TP12. A voltage of less than + 1.0 VDC will indicate the proper signal range applied to the input. If this condition exists, proceed to the next step.

If the D.C. voltage level at TP12 is between + 1.0 and 5.2 VDC with in range signal applied to the input, there may be a filter or level detector circuit problem, (note the flashing display). If a filter circuit problem exists, field repair is not recommended due to the use of critically matched components selected during manufacture of the unit.

9. With a proper in range 180° signal applied as in step 7 and near ground (less than + 1.0 VDC) level AT TP12, the next check should be made at TP3. Connect the oscilloscope to TP3 and adjust for + 5VDC and 10 ms/div. the signal at TP3 is a count gate pulse that is positive going and will be approximately 8.3 ms for 60 HZ. (10.0 ms for 50 HZ).

This pulse will reoccur approximately every $\frac{1}{2}$ second.

If the pulse is present with correct logic level and pulse width, proceed to next step. If not, check circuitry associated with U15-U18 for normal integrated circuit operation as defined in IC manufacturer's data sheets.

10. The number displayed is a clock count recorded during the count gate pulse period described in step 9.

This clock is generated by a phase locked loop circuit synchronized with the input signal applied to input #2. The actual frequency measured at TP4 with a frequency counter will be 216 KHZ for 60 HZ, (180 KHZ for 50 HZ).

The period of the oscillation at TP4 if measured with an oscilloscope will be 4.63 us for 60 Hz, (5.56 us for 50 Hz). With the oscilloscope connected to TP15, one can observe the gated count as applied to the counter/display module.

If the count signal is correct at TP4 and TP15, proceed to step 11. If not, check the components associated to integrated circuits U11-14, U20 for proper operation.

11. The display options (LED or LCD) incorporate integrated circuitry not easily repaired in the field. If a display problem exists, check the ribbon cable for open circuits and the display for damaged components.
12. Switch OFF and disconnect voltage source from inputs 1 and 2.

TESTING BATTERY CHARGER

1. The battery charger is automatic in operation and depends upon the internal resistance of the battery to regulate the amount of charge required.

NOTE: Beware of acid leakage from cracked or damaged battery. Replace cracked or damaged battery.

2. With A-C power cord connected and power switch OFF, measure terminal voltage of battery. Connect DC voltmeter (-) TP10 and (+) CATHODE OF D14. Terminal voltage of a charged battery should be between 5.25V and 6.3V.
3. Switch power ON and battery charger should provide approximately 6.3 - 6.5V to the battery.
4. Under A-C power, the battery is disconnected from the system and is connected only to the charger. The charge current ranges from 10 MA to 200 MA, depending upon the condition of the battery.

NOTES: The battery is classified as a sealed 6 volt 4 amp/hour gel lead acid type. The recommended maximum discharge rate is 400 MA/hr. for 10 hours. The recommended charge rate is less than 200 MA for 20 hours (for a completely discharged battery). The typical float charge for a fully charged battery is about 5 - 10 MA.

Whenever the A-C power is connected to the PAM-275, the battery charger is enabled. Regulator IC VR1 is set to supply the battery with the proper amount of current required to recharge the battery. However, the time required to actually recharge a battery depends on recharge limit.

Regulator IC VR1 has an internal thermal cutout protection feature and cannot recharge a fully discharged battery at high ambient temperatures (over 130°).

The temperature of regulator IC VR1 is a good indication of the battery charger operation (with A-C power cord installed). A warm or hot heat sink indicates a large recharge current. A cool heat sink usually indicates a small amount of charge current.

SERVICE AND REPAIR ORDER INSTRUCTIONS:

If factory service is required or desired, contact the factory for return instructions.

A Service & Repair Order (SRO) number will be assigned for proper handling of the unit when it arrives at the factory.

If desired, a letter with the number and instructions can be provided.

Provide the factory with model number, serial number, nature of the problem or service desired, return address, your name, and where you can be reached should the factory need to contact you.

A purchase order number, cost limit, billing, and return shipping instructions may also be provided if desired.

National Bureau of Standards traceable calibration and certification of two types is available, if desired, at additional cost.

Class One: A certificate is provided verifying the traceability and calibration of the equipment.

Class N: That which is required for nuclear power plants. A certificate of traceability and calibration along with "as found" and "as left" data are provided.

If an estimate is requested, provide the name and contact information of the person with approval/disapproval authority.

Pack the equipment appropriately to prevent damage during shipment. If a reusable crate or container is used, the unit will be returned in it if in suitable condition.

Put the SRO number on the address label of the shipping container for proper identification and faster handling.

NOTE: Ship the equipment without instruction manuals or nonessential items such as test leads, spare fuses, etc. These items are not needed to conduct repairs. Do ship the equipment with all interconnect cables, etc. which make the unit operational.

PREPARATION FOR RESHIPMENT

Save the shipping container that your unit came in. The shipping container your unit came in is designed to withstand the normal bumps and shocks of shipping via common commercial carrier. For example, you may wish to reship your unit to Multi-Amp for annual calibration certification.

WARRANTY STATEMENT


Multi-Amp Corporation warrants to the original purchaser that the product is free from defects in material and workmanship for a period of one (1) year from date of shipment. This warranty is limited and shall not apply to equipment which has damage, or cause of defect, due to accident, negligence, unauthorized modifications, improper operation, faulty installation by purchaser, or improper service or repair by any person, company or corporation not authorized by the Multi-Amp Corporation.

Multi-Amp Corporation will, at its' option, either repair or replace those parts and/or materials that it deems to be defective. Any costs incurred by the purchaser for the repair or replacement of such parts and/or materials shall be the sole responsibility of the original purchaser.

THE ABOVE WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EITHER EXPRESSED OR IMPLIED ON THE PART OF THE MULTI-AMP CORPORATION, AND IN NO EVENT SHALL THE MULTI-AMP CORPORATION BE LIABLE FOR THE CONSEQUENTIAL DAMAGES DUE TO THE BREACH THEREOF.

[illegible][illegible]

REV.	DATE	BY	CHKD.	DESCRIPTION
1	12/23/83	WJG	WJG	DESIGN
2	12/23/83	WJG	WJG	REWORK
3	12/23/83	WJG	WJG	DESIGN
4	12/23/83	WJG	WJG	DESIGN




NOTE:
REFERENCE RGS Y DRAWING 19881C
REFERENCE RGS Y BILL OF MATERIAL 19882B*

MULTI-RMP

REV.	DATE	BY	CHKD.	DESCRIPTION
1	12/23/83	WJG	WJG	DESIGN
2	12/23/83	WJG	WJG	REWORK
3	12/23/83	WJG	WJG	DESIGN
4	12/23/83	WJG	WJG	DESIGN

THIS DRAWING IS THE PROPERTY OF THE COMPANY AND IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT PERMISSION IN WRITING FROM THE COMPANY.

REV	DATE	BY	CHKD	DATE
1	03/07/00	1	14621	03/08/00
2	03/08/00	2	15064	03/08/00
3	03/08/00	3	15064	03/08/00
4	03/08/00	4	15064	03/08/00
5	03/08/00	5	15064	03/08/00
6	03/08/00	6	15064	03/08/00
7	03/08/00	7	15064	03/08/00
8	03/08/00	8	15064	03/08/00
9	03/08/00	9	15064	03/08/00
10	03/08/00	10	15064	03/08/00




- NOTES:
- * REFERENCE TO COMPONENTS NOT MOUNTED ON PCB
 - REF. 205620 ASY. DMG
 - SW1 SWITCH POSITION MUST BE SELECTED PRIOR TO POWERING UP THE UNIT. SW1 IS IN "OFF" POSITION. SW1 IS "ON" POSITION. SW1 IS "OFF" POSITION. SW1 IS "ON" POSITION.
 - HEAT SINK REQUIRED.
 - INSTALL JUMPER JP3 TO DEFEAT DISPLAY TIMER.

THE CIRCUIT SHOWN AND DESCRIBED HEREIN IS A REPRESENTATIVE DESIGN. IT IS NOT A GUARANTEE OF PERFORMANCE. THE USER SHALL BE RESPONSIBLE FOR THE PROPER DESIGN AND CONSTRUCTION OF THE CIRCUIT. THE USER SHALL BE RESPONSIBLE FOR THE PROPER DESIGN AND CONSTRUCTION OF THE CIRCUIT.

AVO MULTI-AMP	(214) 333-1801
CONNECTION	4371 BROWN AVE. DALLAS, TEXAS 75237
FILE	SCHEMATIC - PAM 275
REV. NO.	10275
REV. NO.	204700
REV. NO.	13


PIN NO. 204700	
FUNCTION	
1	2
1	2
3	4
5	6
7	8
9	10
11	12
13	14
15	16
17	18
19	20



THE CIRCUIT SHOWN IS A REPRESENTATIVE DESIGN. THE DESIGNER ASSUMES NO RESPONSIBILITY FOR THE RESULTS OF ANY OTHER DESIGN. THE CIRCUIT IS NOT TO BE USED IN ANY MANNER THAT COULD BE DANGEROUS TO PERSONS OR PROPERTY.

AVO MULTI-AMP	
FORM NO. 204700	REV. 1
DATE	10/27/75
DESIGNED BY	10275
CHECKED BY	10275
APPROVED BY	10275
DATE	10/27/75

REV	DATE	REVISION	BY
1	07/08	REVISED	
2	08/08	REVISED	
3	05/08	REVISED	



- NOTES:
1. 0-5 CONNECTION
 2. 0-5 CONNECTION
 3. 0-5 CONNECTION
 4. 0-5 CONNECTION
 5. 0-5 CONNECTION

REV	DATE	REVISION	BY
1	07/08	REVISED	
2	08/08	REVISED	
3	05/08	REVISED	

pull-amp

COMPONENTS

Q1: 2N3055

Q2: 2N3055

Q3: 2N3055

Q4: 2N3055

Q5: 2N3055

Q6: 2N3055

Q7: 2N3055

Q8: 2N3055

Q9: 2N3055

Q10: 2N3055

Q11: 2N3055

Q12: 2N3055

Q13: 2N3055

Q14: 2N3055

Q15: 2N3055

Q16: 2N3055

Q17: 2N3055

Q18: 2N3055

Q19: 2N3055

Q20: 2N3055

Q21: 2N3055

Q22: 2N3055

Q23: 2N3055

Q24: 2N3055

Q25: 2N3055

Q26: 2N3055

Q27: 2N3055

Q28: 2N3055

Q29: 2N3055

Q30: 2N3055

Q31: 2N3055

Q32: 2N3055

Q33: 2N3055

Q34: 2N3055

Q35: 2N3055

Q36: 2N3055

Q37: 2N3055

Q38: 2N3055

Q39: 2N3055

Q40: 2N3055

Q41: 2N3055

Q42: 2N3055

Q43: 2N3055

Q44: 2N3055

Q45: 2N3055

Q46: 2N3055

Q47: 2N3055

Q48: 2N3055

Q49: 2N3055

Q50: 2N3055

Q51: 2N3055

Q52: 2N3055

Q53: 2N3055

Q54: 2N3055

Q55: 2N3055

Q56: 2N3055

Q57: 2N3055

Q58: 2N3055

Q59: 2N3055

Q60: 2N3055

Q61: 2N3055

Q62: 2N3055

Q63: 2N3055

Q64: 2N3055

Q65: 2N3055

Q66: 2N3055

Q67: 2N3055

Q68: 2N3055

Q69: 2N3055

Q70: 2N3055

Q71: 2N3055

Q72: 2N3055

Q73: 2N3055

Q74: 2N3055

Q75: 2N3055

Q76: 2N3055

Q77: 2N3055

Q78: 2N3055

Q79: 2N3055

Q80: 2N3055

Q81: 2N3055

Q82: 2N3055

Q83: 2N3055

Q84: 2N3055

Q85: 2N3055

Q86: 2N3055

Q87: 2N3055

Q88: 2N3055

Q89: 2N3055

Q90: 2N3055

Q91: 2N3055

Q92: 2N3055

Q93: 2N3055

Q94: 2N3055

Q95: 2N3055

Q96: 2N3055

Q97: 2N3055

Q98: 2N3055

Q99: 2N3055

Q100: 2N3055

